



Polyester distribution boxes

Description

Polyester distribution boxes have been of great advantage in many industrial plants. They offer safe protection even when they are exposed to extreme environmental conditions, aggressive chemical media or high mechanical stress.

The narrow sides within the enclosure hold threaded bushings for the fixing of terminal rails or mounting panels.

The enclosure is mounted by means of insulated screws outside of the lid sealing gasket.

These same high-quality explosion-proofed enclosures are used in hazardous areas by inflammable dust (Zone 21 and 22). The fundamental prerequisites of the "protection through enclosure" protection class are fulfilled with the heating up calculation as per the accompanying sheet and a separate IP protection test. EC model test certification was issued in 2000 by the nominated body IBEExU.

Option

External feet of high-quality stainless steel

Components

Rail-mounted terminals, terminal markers, cable glands, mounting panels, rails, type labels, labels

Installation instructions

The installer must make sure that the enclosure used is suitable for the corresponding field of application. This means that the marking must correspond to the classification of the Ex area. Also must the temperature class of the distribution box meet the respective requirements.

<p><i>IP distribution box</i> <i>EEx e distribution box</i> <i>EEx i distribution box</i></p>	<p><i>black</i> 07-5178-.../... 07-5103-.../... 07-5105-.../...</p>	<p><i>grey</i> 07-5177-.../... 07-5106-.../... 07-5107-.../...</p>
<p>➤ Explosion protection</p> <p>Ex protection type (according to EN 50014)</p> <p>Ambient temperature ranges (special temperature ranges on request)</p> <p>Certifications For Zone 1 and 2 For Zone 21 and 22 (further certifications on request)</p>	<p>⊕ II 2G EEx e II T6 resp. T5 ⊕ II 2G EEx e ia IIC T6 resp. T5 ⊕ II 2D IP 6x T 80 °C</p> <p>-20 °C (-55 °C) to +40 °C at T6 -20 °C (-55 °C) to +55 °C at T5</p> <p>PTB 01 ATEX 1104 IBExU00ATEX1081</p>	<p>⊕ II 2G EEx e II T6 resp. T5 ⊕ II 2G EEx e ia IIC T6 resp. T5</p> <p>-20 °C (-55 °C) to +40 °C at T6 -20 °C (-55 °C) to +55 °C at T5</p> <p>PTB 01 ATEX 1104</p>
<p>➤ Technical data</p> <p>Material</p> <p>Colour</p> <p>Lid screws (other models on request)</p> <p>Standard seals</p> <p>Mechanical resistance according to EN 50014</p> <p>Protection class EN 60529/IEC 60529</p> <p>Rated voltage</p>	<p>glass-fibre reinforced polyester, EN 50014 surface resistance < 10⁹ Ω halogen-free</p> <p>RAL 9005, black</p> <p>stainless steel, captive cross-head (+ -)</p> <p>EPDM -20° C to +100° C silicone -55° C to +100° C</p> <p>impact energy 7 Nm</p> <p>IP 66/IP 67</p> <p>max. 1 100 V</p>	<p>glass-fibre reinforced polyester, EN 50014 surface resistance > 10¹² Ω halogen-free</p> <p>RAL 7000/RAL 7001, grey</p> <p>stainless steel, captive cross-head (+ -)</p> <p>EPDM -20° C to +100° C silicone -55° C to +100° C</p> <p>impact energy 7 Nm</p> <p>IP 66/IP 67</p> <p>max. 1 100 V</p>



The table on this page applies to the following polyester distribution boxes:

IP distribution box black 07-5178-.../... EEx e distribution box black 07-5103-.../... EEx i distribution box black 07-5105-.../...
 IP distribution box grey 07-5177-.../... EEx e distribution box grey 07-5106-.../... EEx i distribution box grey 07-5107-.../...

Rail-mounted terminal components/maximum number					Polyester distribution boxes					
Article no. Polyester distribution boxes	Mini-terminal 07-7902-....		AKZ4 03-7112-0006		WDU 2.5 03-7111-0012		WDU 2.5 bl 03-7111-0012		WDU 4 03-7112-0015	
	TS *	Terminals per rail	TS *	Terminals per rail	TS *	Terminals per rail	TS *	Terminals per rail	TS *	Terminals per rail
07- [] [] [] [] -0800/7555	1	6	1	8	-	-	-	-	-	-
07- [] [] [] [] -1100/7555	1	8	1	13	-	-	-	-	-	-
07- [] [] [] [] -1600/7555	1	12	1	21	-	-	-	-	-	-
07- [] [] [] [] -1900/7555	1	16	1	26	-	-	-	-	-	-
07- [] [] [] [] -2300/7550	1	19	1	32	-	-	-	-	-	-
07- [] [] [] [] -1221/2090	2	8	1	14	-	-	1	16	-	-
07- [] [] [] [] -1221/2012	2	8	1	14	-	-	1	16	-	-
07- [] [] [] [] -2201/2090	2	17	1	30	-	-	1	35	-	-
07- [] [] [] [] -1601/6090	-	-	2	18	1	24	1	23	1	20
07- [] [] [] [] -1601/6012	-	-	2	18	1	24	1	23	1	20
07- [] [] [] [] -2601/6090	-	-	2	34	1	43	1	42	1	34
07- [] [] [] [] -3601/6090	-	-	-	-	1	60	1	62	1	50
07- [] [] [] [] -2552/5012	-	-	-	-	2	43	3	42	2	35
07- [] [] [] [] -2552/5016	-	-	-	-	2	43	3	42	2	35
07- [] [] [] [] -4002/5012	-	-	-	-	2	67	3	70	2	56
07- [] [] [] [] -4002/5016	-	-	-	-	2	67	3	70	2	56
07- [] [] [] [] -4004/0512	-	-	-	-	3	67	5	70	3	56
07- [] [] [] [] -4004/0516	-	-	-	-	3	67	5	70	3	56
07- [] [] [] [] -6002/5012	-	-	-	-	2	108	2	110	1	91

* TS = mounting rail



The table on this page applies to the following polyester distribution boxes:

IP distribution box black 07-5178-.../... EEx e distribution box black 07-5103-.../... EEx i distribution box black 07-5105-.../...
 IP distribution box grey 07-5177-.../... EEx e distribution box grey 07-5106-.../... EEx i distribution box grey 07-5107-.../...

Cable glands/maximum number											
Article no.	Side	M 12 x 1.5	M 16 x 1.5	M 16 x 1.5 extended	M 20 x 1.5	M 20 x 1.5 extended	M 25 x 1.5	M 32 x 1.5	M 40 x 1.5	M 50 x 1.5	M 63 x 1.5
07- [] [] [] [] -0800/7555	A/B C/D	4 1	2 1	2 -	2 -	1 -	1 -	- -	- -	- -	- -
07- [] [] [] [] -1100/7555	A/B C/D	6 1	4 1	3 -	3 -	2 -	2 -	- -	- -	- -	- -
07- [] [] [] [] -1600/7555	A/B C/D	12 1	6 1	5 -	4 -	4 -	3 -	- -	- -	- -	- -
07- [] [] [] [] -1900/7555	A/B C/D	15 1	8 1	6 -	5 -	5 -	4 -	- -	- -	- -	- -
07- [] [] [] [] -1221/2090	A/B C/D	13 4	9 4	5 2	5 2	4 2	3 1	2 1	1 1	1 -	1 -
07- [] [] [] [] -1221/2012	A/B C/D	13 4	9 4	5 2	5 2	4 2	3 1	2 1	1 1	1 -	1 -
07- [] [] [] [] -2201/2090	A/B C/D	28 4	18 4	12 2	11 2	10 2	5 1	3 1	3 1	2 -	1 -
07- [] [] [] [] -1601/6090	A/B C/D	18 8	14 8	8 5	8 4	6 4	4 2	2 2	2 1	1 -	1 -
07- [] [] [] [] -1601/6012	A/B C/D	18 8	14 8	8 5	8 4	6 4	4 2	2 2	1 1	1 -	- -
07- [] [] [] [] -2601/6090	A/B C/D	33 8	26 8	17 5	14 4	12 4	7 2	4 2	3 1	3 -	2 -
07- [] [] [] [] -3601/6090	A/B C/D	48 8	38 8	24 5	20 4	18 4	10 2	6 2	5 1	4 -	3 -
07- [] [] [] [] -2552/5012	A/B C/D	53 12	34 12	23 10	20 8	18 8	9 4	7 3	4 2	3 2	2 2
07- [] [] [] [] -2552/5016	A/B C/D	53 12	34 12	23 10	20 8	18 8	9 4	7 3	4 2	3 2	2 2
07- [] [] [] [] -4002/5012	A/B C/D	88 12	58 12	38 10	35 8	30 8	17 4	13 3	6 2	5 2	4 2
07- [] [] [] [] -4002/5016	A/B C/D	88 12	58 12	38 10	35 8	30 8	17 4	13 3	6 2	5 2	4 2
07- [] [] [] [] -4004/0512	A/B C/D	88 26	58 20	38 16	35 14	30 10	17 6	13 4	6 2	5 4	4 3
07- [] [] [] [] -4004/0516	A/B C/D	135 42	89 38	58 34	53 30	46 24	26 8	20 5	9 3	7 6	4 4
07- [] [] [] [] -6002/5012	A/B C/D	130 12	84 12	56 10	52 8	46 8	24 4	18 3	10 2	6 2	4 2

Each enclosure side wall has only a limited number of gland entries to ensure the mechanical stability of the enclosure.



The table on this page applies to the following polyester distribution boxes:

IP distribution box black 07-5178-.../... EEx e distribution box black 07-5103-.../... EEx i distribution box black 07-5105-.../...
 IP distribution box grey 07-5177-.../... EEx e distribution box grey 07-5106-.../... EEx i distribution box grey 07-5107-.../...

External dimensions, earth bars, mounting panels				Polyester distribution boxes				
Article no.	External dimensions in mm			Earth bars			Mounting panel	
	Length	Width	Height	Type	Order no.	Type	Order no.	
07- -0800/7555	80	75	55	MK 2	05-0012-0006	-	-	05-2105-0002
07- -1100/7555	110	75	55	MK 2	05-0012-0006	-	-	05-2105-0003
07- -1600/7555	160	75	55	MK 2	05-0012-0006	-	-	05-2105-0004
07- -1900/7555	190	75	55	MK 2	05-0012-0006	-	-	05-2105-0005
07- -1221/2090	122	120	90	QS 3	05-0012-0091	LS 4	05-0012-0100	05-0105-0100
07- -1221/2012	122	120	120	QS 3	05-0012-0091	LS 4	05-0012-0100	05-0105-0100
07- -2201/2090	220	120	90	QS 3	05-0012-0091	LS 9	05-0012-0101	05-0105-0101
07- -1601/6090	160	160	90	QS 5	05-0012-0092	LS 5	05-0012-0010	05-0105-0103
07- -1601/6012	160	160	120	QS 5	05-0012-0092	LS 5	05-0012-0010	05-0105-0103
07- -2601/6090	260	160	90	QS 5	05-0012-0092	LS 11	05-0012-0102	05-0105-0104
07- -3601/6090	360	160	90	QS 5	05-0012-0092	LS 16	05-0012-0103	05-0105-0105
07- -2552/5012	255	250	120	QS 9	05-0012-0096	LS 11	05-0012-0105	05-0105-0113
07- -2552/5016	255	250	160	QS 9	05-0012-0096	LS 11	05-0012-0105	05-0105-0113
07- -4002/5012	400	250	120	QS 9	05-0012-0096	LS 18	05-0012-0016	05-0105-0114
07- -4002/5016	400	250	160	QS 9	05-0012-0096	LS 18	05-0012-0016	05-0105-0114
07- -4004/0512	400	405	120	QS 15	05-0012-0097	LS 18	05-0012-0016	05-0105-0117
07- -4004/0516	400	405	160	QS 15	05-0012-0097	LS 18	05-0012-0016	05-0105-0117
07- -6002/5012	600	250	120	QS 9	05-0012-0096	LS 28	05-0012-0106	05-0105-0199